



50 ppm

100 ppm

200 ppm

400 ppm

QAC QR TEST STRIPS

CODE 2951

1. Immerse pad in solution and remove immediately.
2. Hold strip level for 5 seconds. Shake off excess water from pad. Compare pad to color chart above.

NOTE: Sample must be at room temperature (above 75°).
If testing Hyamine 1622, change dip time to 45 seconds in Step 1.
Keep out of sunlight.
Keep vial closed when not in use.



PO BOX 329 • CHESTERTOWN • MARYLAND • 21620
410-778-3100

