

Insta-TEST[®] 4

50 Pool & Spa
Test Strips

**Free Chlorine
(Bromine)**

Alkalinity

pH

Total Hardness

Just SWIRL & READ!

LaMotte



Immerse strip. **SWIRL 3 TIMES***. Remove with pads
face up. DO NOT SHAKE OFF EXCESS WATER.

Read immediately: FCI → Alk → pH → TH

*In cup-size samples, swirl 5 times.



FCI
Free Chlorine
(Bromine)
ppm

Alk
Alkalinity
ppm

pH

TH
Total
Hardness
ppm

0	40	80	120	180	240
0(0)	0.5(1.5)	1(3)	3(6)	5(10)	10(20)
6.2	6.8	7.2	7.6	8.0	8.4
50	100	250	450	800+	

- Keep wet fingers out of the bottle.
- Close cap tightly after removing strip.
- For best results read in natural daylight.
- Store in a cool, dry place.



Code 3029

Chesterstown, MD 21620 www.lamotte.com/insta

