


**Insta-TEST**<sup>®</sup>  
 50 Test Strips  
**Wide Range pH**  
 For potable water & pools  
**Just DIP & READ!**



**LaMotte**



**Wide Range pH**

Using a cup-size sample, immerse strip for **2 seconds**. Remove strip with **pad face up**. **DO NOT SHAKE OFF EXCESS WATER**. With pad still facing up, wait **15 seconds** and **read** the strip. Discard strip after 30 seconds.

- TIPS**
- Keep wet fingers out of the bottle.
  - Cap bottle tightly.
  - Store in a cool, dry place.



**LaMotte** Made in USA  
 Chestertown, MD 21620  
 www.lamotte.com Code 2974

Lot#255621 Exp. 11/06