

**Insta-TEST<sup>®</sup>**  
 50 Test Strips  
**Low Range  
 Hardness**  
 For Potable  
 Water  
**Just DIP  
 & READ!**  
 LaMotte



0
30 (1.7)
60 (3.5)
120 (7.0)
180 (10.5)

**Low Range  
 HARDNESS ppm  
 (gpg)**  
 Using a cup-size sample, immerse strip and remove immediately. Hold strip with **pad face up**. **DO NOT SHAKE OFF EXCESS WATER.** With pad still facing up, wait **15 seconds** and read the strip. Discard strip after 30 seconds.

- TIPS**
- Keep wet fingers out of the bottle.
  - Cap bottle tightly.
  - Store in a cool, dry place.

**LaMotte** Made in USA  
 Chestertown, MD 21620  
 www.lamotte.com



Code 2981