


Insta-TEST[®]
 25 Pool & Spa Test Strips
Peroxide
Just DIP & READ!



LaMotte

Peroxide ppm



TO USE:
 Immerse test strip and remove with pad face up. **DO NOT SHAKE OFF EXCESS WATER.** Immediately compare to color chart.



TIPS

- Keep wet fingers out of the vial.
- For best results, immerse strip to a depth of 12"-18".
- Close vial tightly after removing strip.
- Store in a cool, dry place.



LaMotte

Chestertown, MD 21620 www.lamotte.com/insta

Code 2984

