

Insta-TEST
 50 Test Strips
Peracetic Acid
 High Range:
 0-1000 ppm
Just DIP & READ!



Peracetic Acid ppm



TO USE:

Using a cup-size sample, immerse test strip and remove with **pad face up. DO NOT SHAKE OFF EXCESS WATER.** Wait 10 seconds and compare to color chart immediately.



TIPS

- Keep wet fingers out of the vial.
- Close vial tightly after removing strip.
- Store in a cool, dry place.

 **LaMotte**
 Chestertown, MD 21620
 www.lamotte.com

made in  USA

Code 3000HR

