

Insta-TEST[®] PHOSPHATE TEST STRIPS

2 Pool & Spa Test Strips



1. Fill test tube (0106) to 1.0 mL line.
2. Remove one test strip from foil bag. Seal bag tightly after removing strip. Gently bend strip in half (do not fold) with pads facing inward. Place strip inside test tube cap (as shown).
3. Cap test tube and invert slowly 5 times (invert the tube slowly to allow the bubble to go from the top to bottom and bottom to top).
4. Remove cap and test strip.
5. Place bottom of test tube on white boxed area of color chart. Look down through OPEN test tube (as shown) and compare to color chart.

Look Down Thru Tube



TIPS

- Seal foil bag tightly after removing strip.
- Keep wet fingers out of the foil bag.
- Store in cool, dry place.
- For best results, read in natural light.

LaMotte Company
Chestertown, Maryland
www.lamotte.com/insta

Code 3021
Made in USA

Phosphate ppb

		0
		100
		200
		300
		500
		1000
		2500