



Insta-TEST[®]

50 Test Strips

High Range
Chlorine

0-800 ppm

 LaMotte



High Range
CHLORINE
ppm

made in
USA

Code 3031

In a cup-sized sample, immerse strip for 2 seconds and remove.

Hold strip level (pad face up).

Immediately compare to color chart.



TIPS

- Keep wet fingers out of the vial.
- Close vial tightly after removing strip.
- Store in a cool, dry place.

LaMotte Company
Chestertown, MD 21620 USA
www.lamotte.com

Lot # 9100 Exp. 3/11

