

Insta-TEST[®]
PRO
Phosphate
INSTANT RESULTS!
50 POOL & SPA TEST STRIPS
LaMotte
 Chestertown, MD 21620
 www.lamotte.com/insta

0	100	200	300	500	1000	2500
0	100	200	300	500	1000	2500

Phosphate
ppb

Code 3021-H



1. Fill test tube (0106) to 10 mL line.
2. Remove one test strip from vial. Cap vial tightly after removing strip. Gently bend strip in half (do not fold) with pads facing inward. Place strip inside test tube cap (as shown).
3. Cap test tube and invert slowly 5 times (invert the tube slowly to allow the bubble to go from the top to bottom and bottom to top).
4. Remove cap and test strip.
5. Place bottom of test tube on white boxed area of color chart. Look down through OPEN test tube (as shown) and compare to color chart.

Look Down Thru Tube



TIPS

Cap vial tightly after removing strip. Keep wet fingers out of the vial. Store in cool, dry place. For best results, read in natural light.

