



Insta-TEST[®]

25 Test Strips
25 Tiras de Análisis
25 Bandelettes d'Analyse

Nitrate
Nitrate
Nitrato

LaMotte
Chester town, MD 21620 USA
www.lamotte.com/insta

Dip pad into sample and immerse for 2 seconds. Remove strip with pad face up. **DO NOT SHAKE OFF EXCESS WATER.** In shade, hold pad level for **60 seconds** and read the strip.

- Keep wet fingers out of the bottle.
- Close vial tightly after removing strip.
- Store indoors in a cool, dry, dark place.

Immerger pour 2 secondes dans l'échantillon d'eau. Retirez la bande face vers le haut. NE PAS SECQUER.

À l'ombre, garder le niveau de la bande pour 60 secondes et lire.

- Ne pas introduire les doigts trempés dans le bocal.
- Refermer le capuchon.
- Entreposer dans un endroit frais, sec et ombragé.

Nitrate ppm



Sumerja la tira en la muestra durante 2 segundos. Retírela con el lado coloreado hacia arriba. **NO SACUDA EL EXCESO DE AGUA.** Mantenga la tira horizontal a la sombra por **60 segundos** y haga la lectura.

- No toque el envase con los dedos húmedos.
- Cierre bien el envase luego de sacar la tira.
- Guarde el envase en un lugar frío, seco y oscuro.

Code 3012-G



6 37395 45337 3