

**Insta-TEST**<sup>®</sup>  
 25 Pool & Spa  
 Test Strips  
**Borate**  
**Just DIP  
 & READ!**



**LaMotte**  
 Chestertown, Maryland 21620 USA  
 www.lamotte.com/insta



**Borate\***  
 ppm

0
15
30
50
80

**TO USE:**  
 Immerse strip for 5 seconds.  
 Remove with **pad face up**. **DO NOT SHAKE OFF EXCESS WATER.**  
 Wait 15 seconds and compare to color chart.

- TIPS:**
- Keep wet fingers out of the vial. Close vial tightly.
  - In pools, immerse strip to a depth of 12"-18".
  - In spas, turn off jets and immerse strip to a depth of 6".
  - Store in a cool, dry place.



Code 3017-G  
 \*Patent Pending

