

Insta-TEST[®]

50 Pool & Spa
Test Strips

Free Chlorine
(Bromine)
Alkalinity
pH

*Just swirl &
read instantly!*

 LaMotte




Immerse strip. **SWIRL 3 TIMES***. Remove with **pads face up**. **DO NOT SHAKE OFF EXCESS WATER**. Read immediately: Cl → Alk → pH

*In cup-size samples, swirl 5 times.

Code 2976



Cl
free
chlorine
bromine
ppm



Alk
alkalinity
ppm



pH



Purple color indicates excessive sanitizer

TIPS

- Keep wet fingers out of the v bottle. Keep cap tightly closed.
- In pools, immerse strip to a depth of 12"-18".
- In spas, turn off jets and immerse strip to a depth of 6".
- Store in a cool, dry place.

LaMotte Co., Chestertown, MD 21620 USA www.lamotte.com/insta

6 37395 02976 9

