

biguanide, pH & shock test kit


testing hints

- Take water samples from a depth of about 16" below the water's surface. Never test immediately after adding pool/spa chemicals.
- When adding drops of liquid reagents, always hold the bottle in an upright position to ensure a uniform drop size.
- Read your test results with adequate background light, but away from direct sunlight. To read, hold color block at arms length above the horizon.
- Use the Color Block Cleaning Solution (3993) and the brush (0514) to clean the color block. Rinse the color block thoroughly after cleaning to remove excess cleaner.
- A stained color block or residual detergent will cause inaccurate readings.
- Store kit in a cool dry place away from sunlight. For best results, replace all test kit reagents annually.


WARNING: Keep all reagents out of reach of children. Avoid skin and eye contact. Do not ingest.

biguanide & pH test instructions

1. Dip color block (3377) into the pool or spa and fill to line with sample water (shake out any excess).




- 2.



Add 6 drops of Biguanide Test Solution (3919) to the chamber next to the Biguanide colors.

- 3.



Add 6 drops of pH Test Solution (2023) to the chamber next to the pH colors.

- 4.

Cap and invert to mix. Match sample colors to the color standards and record results.

(Rinse promptly after use.)



biguanide, pH & shock test kit

shock test instructions

- 1** Fill tube (0701) to 5 mL line with water sample.



- 2** Add 1 *Biguanide Shock Tablet (6653) and cap tube.



- 3** Swirl to mix until tablet disintegrates.



- 4** Immediately remove cap and add Biguanide Shock Titrant (6652) dropwise, counting drops. Swirl to mix after each drop.



- 5** Stop when a drop changes the color from pink to colorless. Titration must be completed within 2 minutes.

- 6** Multiply number of drops by 15 to get ppm Biguanide Shock.

Example:
5 drops x 15 = 75 ppm
8 drops x 15 = 120 ppm

LaMOTTE COMPANY

Helping People Solve Analytical ChallengesSM

PO Box 329 • Chestertown • Maryland • 21620 • USA
800-344-3100 • 410-778-3100 (Outside USA) • www.lamotte.com

67017 • 2/06