

Insta-TEST[®] 5

Just SWIRL & READ!

- Free Chlorine (Bromine)
- Total Chlorine
- Alkalinity
- pH
- Total Hardness

50 POOL & SPA TEST STRIPS



Immerse strip. **SWIRL 3 TIMES***. Remove with **pads face up**. **DO NOT SHAKE OFF EXCESS WATER**. Read immediately:
 Cl → TCl → Alk → pH → Hard.

* In cup-size samples, swirl 5 times.



Cl free chlorine (bromine) ppm	0 (0)	0 (1.5)	1 (3)	3 (6)	5 (10)	10 (20)
TCl total chlorine ppm	0	0.5	1	3	5	10
Alk Alkalinity ppm	0	40	80	120	180	240
pH	6.2	6.8	7.2	7.6	8.0	8.4
Hard total hardness ppm	50	100	250	450	800+	

Code 2977
 made in USA



- TIPS**
- Keep wet fingers out of the bottle. Close cap tightly.
 - **In pools**, immerse strip to a depth of 12"-18" and swirl 3Xs. **In spas**, turn off jets and immerse the strip 6" below the water surface and swirl 3Xs.
 - For best results read in natural daylight. Store in a cool, dry place.
- LaMotte Co., Chestertown, Maryland 21620 www.lamotte.com/insta