

**Insta-TEST**<sup>®</sup>  
 25 Test Strips  
**Low Range Free Chlorine**  
 For potable water & pools  
**Just DIP & READ!**



**LaMotte**



|   |      |
|---|------|
| □ | 0    |
| ■ | 0.25 |
| ■ | 0.5  |
| ■ | 1    |
| ■ | 3    |
| ■ | 10   |

**Low Range Free Chlorine** ppm  
 Using a cup-size sample, immerse strip for **2 seconds**. Remove strip with **pad face up**. **DO NOT SHAKE OFF EXCESS WATER**. With pad still facing up, read immediately. Discard strip after 30 seconds.

- TIPS**
- Keep wet fingers out of the bottle.
  - Cap bottle tightly.
  - Store in a cool, dry place.



Lot #72513 Exp. 1/09

Code 2964-G

**LaMotte** Made in USA  
 Chestertown, MD 21620  
 www.lamotte.com