

Insta-TEST[®]

10 Salt Water Test Strips

Sodium Chloride

1500-5000 ppm

Just dip & read!
READY IN 20 SECONDS!





2 Seconds



20 Seconds





Salt Water (SODIUM CHLORIDE) ppm							
1500	2000	2500	3000	3500	4000	4500	5000

TIPS

- Dip pad into sample and immerse for 2 seconds. Remove strip with **pad face up. DO NOT SHAKE OFF EXCESS WATER.** In shade, hold strip level for 20 seconds and compare to color chart. Discard strip after 30 seconds.
- Keep out of direct sun during testing.
- Keep wet fingers out of the bottle and close cap tightly.
- Store indoors in a cool, dry, dark place.

LaMotte Company, Chestertown, MD 21620 Made in USA
www.lamotte.com/insta Code 2998



6 3788345627 6